

Backlit Kit

Set Up Instructions



Attach the White Cloth Diffuser to the quad frame, Hooking it at the joint Pulley, creating an oblique angle, from upper back to lower front joints.



Attach Fluorescent light to the frame poles that are closest to the cloth, as shown at right.



Attach backlit channel bars vertically from joint to joint and position magnetic Backlit Panel.